

Refrigerator Replacement Rebate

List as of 10/30/15

Qualified Products List

- ENERGY STAR®
- 9+ cubic feet



Absocold		Blomberg		Crosley	
Model	Configuration	Model	Configuration	Model	Configuration
ARD1033F*14R/L	TF	BRFB1812SS	BF	CRMH184PS	TF
Arctic King		BRFB1822WH	BF	CRMH184PW	TF
Model	Configuration	BRFD2230SS	BF	CRT10PHS2	TF
ATMA100AEB	TF	BRFD2650SSN	BF	CRT10PHW2	TF
ATMA100AES	TF	Bosch		CRT12PHS2	TF
ATMA100AEW	TF	Model	Configuration	CRT12PHW2	TF
ATMA115AEB	TF	B10CB80NVB	BF	CRT151HQ*	TF
ATMA115AES	TF	B10CB80NVS	BF	CRT151HQ*	TF
ATMA115AEW	TF	B10CB80NVW/01	BF	CRT182HQ*	TF
Avanti		B11CB50SSS/01	BF	CRT182HQ*	TF
Model	Configuration	B11CB80SSS/01	BF	CRT186HQ*	TF
FF116DOW	TF	B11CB81SSS/01	BF	CRT186HQ*	TF
FF120WH	TF	B30BB830SS	BF	CRT206HQ*	TF
FF122PH	TF	B30IB800SP	BF	CRT206HQ*	TF
FF99D0W	TF	B30IR800SP	RO	Dacor	
FF99D2P	TF	B36BT830NS	BF	Model	Configuration
FF99D3S	TF	B36IT800NP	BF	RF36NDFSS*	BF
FFBM102DOW	BF	Crosley		Daewoo	
FFBM102D2P	BF	Model	Configuration	Model	Configuration
FFBM102D3S	BF	CDT2181H*	TF	FR-1020ARS	TF
Beko		CFD28SDQ*	BF	FR-1020ARW	TF
Model	Configuration	CFD28WIQ*	BF	FRG2171BN*	TF
BFFD3622SS	BF	CRMH10PD	TF	RFS-25AEDA**	BF
Blomberg		CRMH10PW	TF	Danby	
Model	Configuration	CRMH12PD	TF	Model	Configuration
BRFB1152SSN	BF	CRMH12PS	TF	DFF092C1BSLDB	BF
BRFB1452SSN	BF	CRMH12PW	TF	DFF092C1WDB	BF
		CRMH184PB	TF		

Qualified Refrigerator Models Seattle City Light

Page 1 of 8

TF = Top Freezer BF = Bottom Freezer SS = Side-by-Side RO = Refrigerator Only SD = Refrigerator/Freezer Single Door

* = denotes arbitrary variable number/letter

Danby

Model	Configuration
DFF103A4WDB	TF

Danby Designer

Model	Configuration
DAR110A1*	RO
DFF100C2BSLDD	TF
DFF100C2BSSDD	TF
DFF100C2WDD	TF
DFF123C2BSSDD	TF
DFF123C2WDD	TF

DCS

Model	Configuration
RS36(X)	BF

Electrolux

Model	Configuration
EI11BF25QS	BF
EI23BC30K**A	BF
EI23BC35K**A	BF
EI23BC60K**A	BF
EI23BC65K**A	BF
EI26SS30J**A	SS
EI28BS65K**A	BF

Emerald Chef

Model	Configuration
RF 2105B	TF
RF 2105SS	TF
RF 2105W	TF
RF1003ESW	TF
RF1004ESBB	TF
RF1004ESSS	TF
RF1802SS	TF
RF1802W	TF

Emerald Cool

Model	Configuration
RF 1203ESSS	TF
RF1003 ESW	TF
RF1004ESBB	TF
RF1004ESSS	TF
RF1203ESSS	TF
RF1203ESW	TF
RF1203ESW	TF
RF1802B	TF
RF1802SS	TF
RF1802W	TF

Fagor

Model	Configuration
BMF-200X	BF

Fisher & Paykel

Model	Configuration
E522B*****	BF
E522B*****	BF
RF170W*****	BF
RF170W*****	BF
RF201A*****	BF
RF201A*****	BF
RS36(X)	BF

Frigidaire

Model	Configuration
DGHF2360P**A	BF
DGUS2645L**A	SS
FFED2322Q*	BF
FFEG2322Q*	BF
FFEN2822Q*	BF
FFET1022Q*	TF
FFET1222Q*	TF
FFEX2315Q*	SS
FFHB2740P**A	BF
FFHI1831Q*	TF

Frigidaire

Model	Configuration
FFHI2131Q*	TF
FFHN2740P**A	BF
FFHT1514Q*	TF
FFHT1514Q*	TF
FFHT1521Q*	TF
FFHT1614Q*	TF
FFHT1614Q*	TF
FFHT1621Q*	TF
FFHT1621Q*	TF
FFHT1814Q*	TF
FFHT1814Q*	TF
FFHT1821Q*	TF
FFHT1821Q*	TF
FFHT1831Q*	TF
FFHT1831Q*	TF
FFHT2021Q*	TF
FFHT2021Q*	TF
FFHT2131Q*	TF
FFHT2131Q*	TF
FGEB28D7R*	BF
FGEX2631Q*	SS
FGEX26D6Q**A	SS
FGHB2866P*	BF
FGHB2866P**A	BF
FGHF2366P**A	BF
FGHF2367Q*	BF
FGHG2366P**A	BF
FGHI1864Q*	TF
FGHI2164Q*	TF
FGHN2866P**A	BF
FGHS2355P**A	SS
FGHS2631P**A	SS
FGHS2655P**A	SS
FGHT1846Q*	TF
FGHT1846Q*	TF
FGHT2046Q*	TF

Frigidaire

Model	Configuration
FGHT2046Q*	TF
FPHB2899P*	BF
FPHB2899P**A	BF
FPHF2399P*	BF
FPHF2399P**A	BF
FPHG2399P**A	BF
FPHS2399P**A	SS
FPHS2699P**A	SS
FPHT18D3R*	TF
FPHT18D3R*	TF
LFHB2741P**A	BF
LFHT1831Q*	TF
LFHT1831Q*	TF
LFHT2131Q*	TF
LFHT2131Q*	TF
LGHB2867P*	BF
LGHB2867P**A	BF
LGHT1846Q*	TF
LGHT1846Q*	TF
LGHT2046Q*	TF
LGHT2046Q*	TF

Frigidiare

Model	Configuration
FFHT1521Q*	TF

Gaggenau

Model	Configuration
RB472701	BF
RB492701	BF
RC462701	RO
RC472701	RO
RY492701	BF

Gallery

Model	Configuration
FGVU17F8QF*	RO

Gallery

Model	Configuration
FGVU17F8QT*	RO
FGVU17F8QW*	RO
FGVU21F8QF*	RO
FGVU21F8QT*	RO
FGVU21F8QW*	RO

GE

Model	Configuration
DfE28JGH****	BF
DfE28JMH****	BF
DfE28JSH****	BF
DSE25JGH****	SS
DSE25JMH****	SS
DSE25JSH****	SS
GBE10ESJ****	BF
GDE20GGH****	BF
GDE20GMH****	BF
GDE20GSH****	BF
GDE23GGH****	BF
GDE23GSH****	BF
GFE26GGH****	BF
GFE26GMH****	BF
GFE26GSH****	BF
GFE28HGH****	BF
GFE28HMH****	BF
GFE28HSH****	BF
GIE16DGH****	TF
GIE16GSH****	TF
GIE18CTH****	TF
GIE18ETH****	TF
GIE18GCH****	TF
GIE18GSH****	TF
GIE18GTH****	TF
GIE18HGH****	TF
GIE18HSH****	TF
GIE18ISH****	TF

GE

Model	Configuration
GIE21GSH****	TF
GIE21GTH****	TF
GNE29GGH****	BF
GNE29GMH****	BF
GNE29GSH****	BF
GPE16DTH****	TF
GPE16DTH****	TF
GSE22ESH****	SS
GSE22ETH****	SS
GSE25ESH****	SS
GSE25ETH****	SS
GSE25GGH****	SS
GSE25GSH****	SS
GSE25HGH****	SS
GSE25HMH****	SS
GSE25HSH****	SS
GTE15CTH****	TF
GTE15CTH****	TF
GTE15NTH****	TF
GTE15NTH****	TF
GTE15NTH****	TF
GTE16DTH****	TF
GTE16DTH****	TF
GTE16DTH****	TF
GTE16GSH****	TF
GTE16GSH****	TF
GTE16GTH****	TF
GTE16GTH****	TF
GTE18CCH****	TF
GTE18CCH****	TF
GTE18CTH****	TF
GTE18CTH****	TF
GTE18ETH****	TF
GTE18ETH****	TF
GTE18GMH****	TF
GTE18GMH****	TF
GTE18GSH****	TF
GTE18GSH****	TF

GE

Model	Configuration
GTE18GTH****	TF
GTE18GTH****	TF
GTE18IGH****	TF
GTE18IGH****	TF
GTE18ISH****	TF
GTE18ISH****	TF
GTE18ITH****	TF
GTE18ITH****	TF
GTE18LGH****	TF
GTE18LGH****	TF
GTE18LMH****	TF
GTE18LMH****	TF
GTE18LSH****	TF
GTE18LSH****	TF
GTE21GSH****	TF
GTE21GSH****	TF
GTE21GTH****	TF
GTE21GTH****	TF
GTE21GTH****	TF
GYE22KMH****	BF
GYE22KSH****	BF

GE Artistry

Model	Configuration
ABE20EGH****	BF
ABE20EGH****	BF

GE Cafe

Model	Configuration
CFE28TSH****	BF
CFE28USH****	BF
CWE23SSH****	BF
CYE22TSH****	BF
CYE22USH****	BF

GE Monogram

Model	Configuration
ZIC30GNH****	BF

GE Monogram

Model	Configuration
ZIC360NH****	BF
ZICP360NH****	BF
ZICS360NH****	BF
ZIR360NH****	RO
ZIRP360NH****	RO
ZIRS360NH****	RO
ZWE23ESH****	BF
ZWE23PSH****	BF

GE Profile

Model	Configuration
PFE28RSH****	BF
PFH28PSH****	BF
PSE25KGH****	SS
PSE25KSH****	SS
PWE23KGD****	BF
PWE23KMD****	BF
PWE23KSD****	BF
PYE22PSH****	BF

Haier

Model	Configuration
HRF24E3APS	BF
HRT18F2A**	TF
HRT21F2A**	TF
HT18TS78**	TF
HT21TS78**	TF
HT21TS85**	TF

Hanover

Model	Configuration
HANRT10C*	TF
HANRT12C*	TF

Hisense

Model	Configuration
RB12N1ESE	BF
RB12N6PSE	BF

Hisense

Model	Configuration
RB14N6ASE	BF
RB17N6ASE	BF
RD-46WC1H*	BF
RF20N6ASE	BF

Hotpoint

Model	Configuration
HPE15BTH****	TF
HPE15BTH****	TF

Ikea

Model	Configuration
IX3HHEXDS*	BF
IX6HHEXDS*	BF
IX7DDEXDS*	BF
IX7HHEXDS*	BF

Jenn-Air

Model	Configuration
JB36NXFXLE**	BF
JB36NXFXRE**	BF
JB36SSFX*A**	BF
JFC2089BE*	BF
JFX2597AE*	BF
JS42PPDUDE**	SS
JS42SSDUDE**	SS
JS48PPDUDE**	SS
JS48SSDUDE**	SS

Kenmore

Model	Configuration
253.7041*41	BF
2536011*41	TF
2536011*41	TF
2536031*41	TF
2536031*41	TF
2536038*41	TF
2536038*41	TF

Qualified Refrigerator Models Seattle City Light

TF = Top Freezer BF = Bottom Freezer SS = Side-by-Side RO = Refrigerator Only SD = Refrigerator/Freezer Single Door

* = denotes arbitrary variable number/letter

Kenmore

Model	Configuration
2536060*41	TF
2536060*41	TF
2536062*41	TF
2536062*41	TF
2536768*41	TF
2536768*41	TF
2537034*21	BF
2537034*41	BF
2537042*41	BF
2537044*21	BF
2537044*41	BF
2537060*41	TF
2537062*41	TF
2537063*41	TF
5172*41*	SS
5176****	SS
5182#	SS
6935*	BF
6936*	BF
6938*	BF
7131#	BF
7132#	BF
7160#	BF
7248#	BF
7303#	BF
7305#	BF
7306#	BF
7313#	BF
7401#	BF
7402#	BF
7403#	BF
7404#	BF
7405#	BF
7409#	BF
7902#	BF
7904#	BF

Kenmore

Model	Configuration
7931***	BF
7934***	BF
7941*	BF
7942*	BF
7946*	BF
7998#	BF
7999#	BF
970R4242*	TF
970R4242*	TF
970R4243*	TF
970R4243*	TF
970R4244*	TF
970R4244*	TF
970R4245*	TF
970R4245*	TF
970R4246*	TF
970R4246*	TF
970R7240*	BF
970R7242*	BF
970R7243*	BF

KFN 14943 SD

Model	Configuration
KFN 14943 SD	BF

KitchenAid

Model	Configuration
KB*S19KC*	BF
KB*S22KC*	BF
KBBL206EPA**	BF
KBBL206ESS**	BF
KBBL306EPA**	BF
KBBL306ESS**	BF
KBBR206EPA**	BF
KBBR206ESS**	BF
KBBR306EPA**	BF
KBBR306ESS**	BF

KitchenAid

Model	Configuration
KBBX104***	BF
KBFN402EPA**	BF
KBFN402ESS**	BF
KBFN502EBS**	BF
KBFN502EPA**	BF
KBFN502ESBOO**	BF
KBFN502ESS**	BF
KBFS20EC*	BF
KBFS22EC*	BF
KBFS25EC*	BF
KBLC36FTS**	BF
KBLO36FTX**	BF
KBRC36FTS**	BF
KBRO36FTX**	BF
KBSD502ESS**	SS
KBSD508ESS**	SS
KBSD602ESS**	SS
KBSD608EBS**	SS
KBSD608ESS**	SS
KBWG11NCSS	BF
KFXS25RY*	BF
KRBL102ESS**	BF
KRBL109ESS**	BF
KRBR102ESS**	BF
KRBR109ESS**	BF
KRBX102E****	BF
KRBX109E****	BF
KRFC300E****	BF
KRFF302E****	BF
KRFF305E****	BF
KRSF505*****	SS
KSSC42QVS**	SS
KSSC48QVS**	SS

Maytag

Model	Configuration
MFT2574DE*	BF
MFT2776DE*	BF
MFT2778EE***	BF

MEILING

Model	Configuration
BCD-260WHA	BF
MRF-276W	BF
MRF-280WFA	TF
MRF-340WEA	TF

MicroFridge

Model	Configuration
10.3LMF4-9D1	TF
10.3LMF4-9D1W	TF
10.3LMF4-9D1WX	TF
10.3LMF4-9D1X	TF
10.3LMF4-9TPWX	TF
10.3LMF4-9TPX	TF
10.3LMF4R	TF
10.3LMF4RW	TF
10.3RMF4-9D1	TF
10.3RMF4-9D1W	TF
10.3RMF4-9D1WX	TF
10.3RMF4-9D1X	TF
10.3RMF4-9TP	TF
10.3RMF4-9TPWX	TF
10.3RMF4-9TPX	TF
10.3RMF4R	TF
10.3RMF4RW	TF

Midea

Model	Configuration
HD-366FWEN(SZ)	TF
HD-368RWE(SZ)	BF
HD-368RWES	BF
HD-423FWEN(SZ)	TF

Midea

Model	Configuration
HD-663FWEN(SZ)	TF
HD-663W	TF
HD-774FW	TF
UR-BCD280WE-S	TF
UR-BCD326WE-S	TF
WHD-366FWEW1	TF

Miele

Model	Configuration
K1803 Vi	RO
K1903 Vi	RO
KF1803 Vi	BF
KF1903 Vi	BF
KFN 14943 SDE	BF
KFN 9855iDE	BF
KNF 12823 SD edt/cs-2	BF
KS 37472iD	RO

Moffat

Model	Configuration
MBR12DGH****	BF
MBR12DSH****	BF

Samsung

Model	Configuration
RF23HC*DB**	BF
RF23HC*DT**	BF
RF23HS*SB**	BF
RF23HT*DB**	BF
RF23J9011**	BF
RF24FS*DB**	BF
RF24J9960**	BF
RF25HM*DB**	BF
RF260B*AE**	BF
RF261BEAE**	BF
RF261BIAESR	BF
RF263B*AE**	BF

Samsung

Model	Configuration
RF263T*AE**	BF
RF26HF*ND**	BF
RF26HFPNB**	BF
RF26J7500**	BF
RF28HD*DB**	BF
RF28HD*DP**	BF
RF28HD*DT**	BF
RF28HF*DT**	BF
RF28HFEDB**	BF
RF28HFPDB**	BF
RF28HM*DB**	BF
RF28HM*LB**	BF
RF28JB*DB**	BF
RF30HB*DB**	BF
RF30HD*DT**	BF
RF31FM*DB**	BF
RF31FM*SB**	BF
RF323T*DB**	BF
RF32FM*DB**	BF
RF34H9950**	BF
RF34H9960**	BF
RH22H9010*	SS
RH25H5611**	SS
RH29H9000**	SS
RH30H9500**	SS
RL220N*TA**	BF
RL225N*TA**	BF
RS22HD*PN**	SS
RS25H5111**	SS
RS25H5121**	SS

Smeg

Model	Configuration
FTU171*7	BF

Sub-Zero

Model	Configuration
BI-30U/**	BF
BI-36R/**	RO
BI-36U/**	BF
BI-42S/S/**	SS
BI-48S/S/**	SS
IC-24R	RO
IC-30R**	RO
IC-36R**	RO
IT-30CI**	BF
IT-30R**	RO
IT-36CI**	BF
IT-36R**	RO

Summit

Model	Configuration
FF1084W	TF
FF1085SS	TF
FF1118W	TF
FF1119B	TF
FF1159SS	TF
FF1386W	TF
FF1387SS	TF
FFBF100W	BF
FFBF101SS	BF
FFBF191SS	BF
FFBF240WX	BF
FFBF280WX	BF

Thermador

Model	Configuration
T24IR800SP	RO
T30BB810SS	BF
T30BB820SS	BF
T30IB800SP	BF
T30IR800SP	RO
T36BB810SS	BF
T36BB820SS	BF

Thermador

Model	Configuration
T36BT810NS	BF
T36BT820NS	BF
T36IB800SP	BF
T36IT800NP	BF

VIKING

Model	Configuration
FDSB5423*****	SS
FDSB5483*****	SS
VCSB5423*****	SS
VCSB5483*****	SS

Whirlpool

Model	Configuration
CB345W	BF
WRB119WFB*	BF
WRB322DMB	BF
WRB329*FB*	BF
WRB329DMB*	BF
WRB551WNBS	BF
WRF532SMB*	BF
WRF532SNB*	BF
WRF535SMB*	BF
WRF535SWB*	BF
WRF540CWB*	BF
WRF736SDA*	BF
WRF757SDE***	BF
WRF767SDE***	BF
WRS331FDD*0*	SS
WRS335FDD***	SS
WRS586FID*	SS
WRS586FIE***	SS
WRS586FLD*	SS
WRS975SID***	SS
WRT134TFD*0*	TF
WRT138FZD*	TF
WRT148FZD*	TF

Whirlpool

Model	Configuration
WRT348FME*0*	TF
WRT541SZD*0*	TF
WRT549SZD*	TF